

1. Easy Simple マイサーバーを送信画像サーバーとして使用する

Controller EasyS(Simple) ver 01B Jan 2022 by JQ1HDR Test 03/Dec 2021

Setting TX RX Slide Wall DigiSite HTML

①

自局のコール JQ1HDR ☒ Japanese ☒ マイサーバー使用 ☐ SSTV運用

運用バンド 7.172MHz ☒ 自動スタート ☒ Who is On Air

使用プログラム
☐ JTDX ☒ WSJT-X Log C:\Users\jq1hd\AppData\Local\WSJT-X Set

モード
☒ FT8 ☒ PSK(Vari) ☒ QSO
☐ MSK144 (15s) ☒ Short TX

TX画像サイズ
最大幅 1400 最大高さ 1280
☒ 小さな画像の拡大取り込み

プログラムの状況

*** URLマスターをリフレッシュしました。***
Received : 202112041036431_JA7ESW.jpg
Upload to DigiSite

Receiving Process Starts
Received : 202112041033131 JA7ESW.jpg

受信データ
211204_031145 7.074 Rx FT8 20 0.4 1611 JA2FBE/IMAGE

06:16:58 UTC

マクロ時刻
☐ UTC ☐ Peanut On/Off

☒ Easy受信画像保存数 100
☒ SSTV受信画像保存数 50
☐ FT8/MSK受信時RXタブに移動
☐ SSTV受信時YoniQRXタブに移動
☒ HTML受信 ☒ HTML送信
☐ 2番目起動のシンプル

パラメーター設定
受信タイミング sec 2 JTDX Log 202112 ☐ JTDX/WSJT-Xのマクロを使用 1

サーバ設定
☐ デジサイト ☒ マイサーバー 1

登録名称 JQ1HDR ③ 設定保存 ⑥

FTPサーバ sv27.star.ne.jp

ID #####

パスワード ##### ⑤

ディレクトリ ft8

登録URL http://jq1hdr.stars.ne.jp/ft8/ ④

☒ 画像/HTML送信をマイサーバーで行う 使用サーバ ⑧ JQ1HDR2
☐ ID/パスワード表示 ☐ デジサイトをリフレッシュしない

マスター設定
名前登録
拒否局登録
マスター更新

ReSet
TX画像リセット
SSTV画像リセット
PSKフォルダー変更

マイサーバーを送信画像サーバーとして使用方法

- ① マイサーバー使用にチェックを入れる。
- ② マイサーバーとして URL マスターに登録されている方は マイサーバーが使用できるようになります。 まず、登録した URL のデーターを設定します
- ③ 登録されているサーバーが表示されます。 設定するサーバーを選んでください。
- ④ 登録されている URL 名が表示されるので、その URL に対する
- ⑤ サーバーFTP、ID、パスワード、ディレクトリーをインプットしてください。
- ⑥ 設定内容を保存してください。
- ⑦ マイサーバーを使用するときにチェックを入れてください。
- ⑧ 登録し使用するサーバーを選んでください。

なお、マイサーバーを登録していない場合はマイサーバーを e-Mail でお知らせください。 E-Mail 先は QRZ.com にあります。
コールサイン、登録する URL を記入ください。 ID やパスワードは不要です。

1 Easy Simple How to use My Server as TX image server

Controller EasyS(Simple) ver 01B Jan 2022 by JQ1HDR Test 03/Dec 2021

Setting TX RX Slide Wall DigiSite HTML

My Call JQ1HDR ☐ Japanese ☒ Use My Server ☐ Use SSTV

On Air Band 7.172MHz ☒ Auto Start ☒ Who is On Air

Used Program
☐ JTDX ☒ WSJT-X Log C:\Users\jq1hd\AppData\Local\WSJT-X Set

Mode
☒ FT8 ☒ PSK(Vari) ☒ QSO
☐ MSK144 (15s) ☒ Short TX

TX Picture Size
Max Width 1400 Max Height 1280
☒ Expansion when smaller pic is loaded

Program Status
*** URLマスターをリフレッシュしました。***
Received : 202112041036431_JA7ESW.jpg
Upload to DigiSite
Receiving Process Starts
Received : 202112041033131 JA7ESW.jpg
Received Data
211204_031145 7.074 Rx FT8 20 0.4 1611 JA2FBE/IMAGE

Macro Time
☐ UTC ☐ Peanut On/Off
☒ Max Easy RX Image 100
☒ Max SSTV RX Image 50
☐ Move to FT8/MSK RX Image Tab
☐ Move to SSTV RX Image Tab
☒ Receive HTML ☒ Send HTML
☐ 2nd Simple Program

Parameter Setting
Decode Timing sec 2 JTDX Log 202112 ☐ Use JTDX/WSJT-X Macro 1

Server Setting
☐ DigiSite ☒ My Server for TX 1
Server Name JQ1HDR ☒ Save ☒
FTP server sv27.star.ne.jp
ID ##### ☒
Password ##### ☒
Dir ft8
Registered URL http://jq1hdr.stars.ne.jp/ft8/ ☒
☒ Use My Server for IMAGE and HTML Using Server JQ1HDR2 ☒
☐ Show ID/Pswd ☐ No Refresh DigiSite

Master Setting
Name List
Refuse List
Refresh Master

ReSet
TX Image Reset
SSTV Image Reset
PSK Folder Change

How to use My Server as a TX image server

- ② Check use My Server.
- ② If you are registered in the URL master as My Server, you will be able to use My Server. Set the all data of the registered URL.
- ③ The registered server is displayed. Select the server to set.
- ④ The registered URL name will be displayed so for that URL
- ⑤ Enter the server FTP, ID, Password and directory.
- ⑥ Save the settings.
- ⑦ Check this when using My Server.
- ⑧ Select the registered server to use

If you have not registered My Server, please let us know your server by e-mail. The e-mail is at QRZ.com.

Please send the callsign and URL to register. No ID and Password is required.